











Thank you for purchasing this quality product!


Please read instructions carefully prior to assembly.

Check carefully for small parts which may have come loose during transportation inside all the boxes. Remove from boxes and place all parts and components on soft surface such as carpet, blanket or furniture pad. Identify and verify all parts and hardware as specified below.

NO.	DESCRIPTION	OUTLOOK	SIZE	QT	NO. DESCRIPTION	OUTLOOK	SIZE	QT
1	WINGS LAF AND RAF		9.5x27x5.9	2	6		66.6"36"25.6	1
2	LFL & RFL CUSHION FOR LAF AND RAF		31.5x9.8x3.6	2	7		31.5"20"5.9	2
3	CONSOLE BACKS		31.5x9.8x3.6	2	8		51"29"20	1
4	RIGHT SIDE CUSHION FOR LAF AND RAF		31.5x9.8x3.6	2	9			1
5	LAF LOWSEAT SEAT BASE		66.6"36"25.6	1	10			2

### Installation Steps:


#### STEP 1



Install back cushions (2), (3) and (4) on the LAF Lowseat seat base (5)

Then, install LAF wing (1) on the LAF Lowseat seat base (5)


#### STEP 3



Install back cushions (2), (3) and (4) on the RAF Lowseat seat base (6)


Then, install LAF armrest (1) on the RAF Lowseat seat base (6)

#### STEP 2




Install back cushions (7) x 2 on the wedge seat base (8)

#### STEP 4



Assemble together each piece of the sectional using pre-installed back connectors

#### STEP 4



Plug in power plug (10) x 2 to the back of LAF and RAF between and power adapter into wall outlet. Plug in speaker power plug on the back of the console and other end of sofa outlet.