

**STEP 1**

**STEP 2**

**STEP 3**

**STEP 4**

**STEP 5**

**COMPLETED ASSEMBLY**

**NO PART LIST**

NO	DESCRIPTION	QTY
A	Headboard	1 pc
B	Headboard Leg	2 pcs
C	Footboard	1 pc
D	Footboard Leg	2 pcs
E	Side Rail	4 pcs
F	Siderail Support Leg	2 pcs
G	Center Support Leg	4 pcs
H	Bed Slat	4 pcs
<b>NO HARDWARE LIST</b>		
1	JCBB M8 x 25mm	8 pcs
2	JCBC M6 x 25mm	8 pcs
3	JCBC M6 x 40mm	10 pcs
4	JCBC M6 x 70mm	2 pcs
5	Spring Washer M6	14 pcs
6	Flat Washer M6	14 pcs
7	Allen Key M4	1 pc
8	Allen Key M5	1 pc
9	Adjuster M6	4 pcs
10	CSK M4 x 30mm	8 pcs
11	Dowel M6	4 pcs

**CAUTION:**

1. Do not FULLY - TIGHTEN the nut or screw until all hardware and furniture part fit for guidance. Be sure you have all wooden furniture parts on a clear and flat soft surface, such as a carpet or rug, to prevent from being scratched.

2. Do not OVER - TIGHTEN the nut or screw to avoid causing damages to the thread.

3. Keep all hardware part out reach of children.

Read this instruction carefully. Remove all wrapping material, staples and straps from the carton. See hardware and furniture part list for guidance. Be sure you have all wooden furniture parts on a clear and flat soft surface, such as a carpet or rug, to prevent from being scratched.

SCREW DRIVER  
1 X 2 People  
NOT INCLUDED